



ILLUSTRATED PARTS LIST FOR



SINGER Machine

107G235

THE SINGER COMPANY




107 G 235 - 10 (0671)

160-850	ARM COVER (TOP) SCREW (2)
160-850	FACE PLATE SCREW
1186-850	ARM COVER (TOP) SCREW (2)
1186-850	FACE PLATE SCREW
1654-850	THREAD RETAINER NUT
51220-853	THREAD GUIDE (UPPER) SCREW
200582-850	THREAD GUIDE (LOWER) SCREW

202412	THREAD GUIDE (ON TOP OF ARM)
210593	THREAD GUIDE (LOWER)
502667	THREAD RETAINER
508153	ARM COVER (TOP)
508154	FACE PLATE
508166	THREAD GUIDE (UPPER)

PART NO. DESCRIPTION

PART NO. DESCRIPTION



107 G 235 - 20 (0671)


238-650	BED SLIDE SPRING SCREW (2)
141566-633	MACHINE PULLEY POSITION SCREW
141567-633	MACHINE PULLEY SET SCREW
200577-633	BED PLATE SCREW (2)
200577-633	BED PLATE (BACK) SCREW (2)
210505	BED PLATE (BACK)
210616	BED SLIDE (FRONT) CPL. NOS. 508506 AND TWO EACH 238
224485	THROAT PLATE

272142	ARM SHAFT BALL (BACK)
500196-850	MACHINE GROUNDING WIRE SCREW
500350-850	TAKE-UP LEVER GUARD SCREW (2)
508150	MACHINE PULLEY CPL. NOS. 141566, 141567 AND 272142
508167	ARM SHAFT BUSHING (FRONT) OIL PACKING PLUG
508168	NEEDLE BAR FRAME CAP
508216	TAKE-UP LEVER GUARD
508506	BED SLIDE SPRING
512008	MACHINE GROUNDING WIRE LOCK WASHER
603291	MACHINE GROUNDING WIRE SYMBOL

PART NO. DESCRIPTION

PART NO. DESCRIPTION


NEEDLE BAR AND TAKE-UP MECHANISM



200132-B50	TAXI-UP/AUXILIARY SCREW
200335-B50	NEEDLE BAR CRANK SET SCREW
200341-B50	ARM SHAFT BUSHING (FRONT) SET SCREW
200374-B50	NEEDLE BAR CONNECTING LINK STUD SET SCREW
200382-B50	TAXI-UP LEVER HINGE STUD SET SCREW
200383-B50	NEEDLE BAR CONNECTING LINK STUD SET SCREW
200387-B50	NEEDLE BAR SET SCREW
200388-B50	NEEDLE BAR CRANK LOCK SCREW
200452-B50	NEEDLE BAR CRANK POSITION SCREW
200744	ARM SHAFT BUSHING (FRONT) PACKING (WICK)
200749	ARM SHAFT WITH 204392
200759	NEEDLE BAR CONNECTING STUD OIL PACKING (WICK)
200769	NEEDLE BAR CONNECTING LINK STUD OIL PACKING (WICK)
200783	NEEDLE BAR CONNECTING LINK STUD WITH 202259
200899	TAXI-UP LEVER DRIVING STUD WITH 204451
200930	TAXI-UP LEVER HINGE STUD WITH 202403
200933	TAXI-UP LEVER HINGE STUD OIL PACKING (WICK)
200972	NEEDLE BAR CRANK FRICTION WASHER

207080 ARMA SHAFT BUSHING (FRONT) WITH 202244
210543 NEEDLE BAR CONNECTING LINK
210544 NEEDLE BAR CONNECTING STUD WITH 202799
210585 NEEDLE BAR CONNECTING STUD CPL. NOS. 210544
AND 210582
210591 TAKE-UP AUXILIARY
210725 NEEDLE BAR CRANK CPL. NOS. 200335, 200374, 200383,
200432 AND 202233
210882 NEEDLE BAR CONNECTING STUD SWIVEL WITH 200387
210883 NEEDLE BAR CRANK CPL. NOS. 202399, 202400, 210543,
210585, 210725 AND 244259
224392 ARMA SHAFT OIL PACKING (WICK)
244029 TAKE-UP LEVER
244071 TAKE-UP LEVER DRIVING STUD OIL PACKING (WICK)
396535 NEEDLE BAR CRANK WITH TAKE-UP (AUXILIARY) CPL.
NOS. 200132, 210591 AND 210883


107 G 235 - 30 (0671)



107 G 235 - 40 (0671)

1901-16-1	NEEDLE
200070-650	NEEDLE BAR FRAME PITMAN ECCENTRIC STUD SET SCREW
200125-633	NEEDLE SET SCREW
200172-650	THREAD GUIDE SCREW
200175-650	NEEDLE THREAD GUIDE SCREW
200334-633	NEEDLE BAR FRAME HINGE
210542-633	NEEDLE BAR FRAME CPL. NOS. 210546 AND 224317
210542	NEEDLE BAR FRAME CPL. NOS. 210546 AND 224317
210546	NEEDLE BAR FRAME WITH 200070

210542	NEEDLE BAR FRAME GUIDE STUD
210557	NEEDLE BAR FRAME PITMAN ECCENTRIC STUD
224317	NEEDLE BAR CPL. NOS. 200125, 200175 AND 249270
224387	NEEDLE BAR FRAME HINGE STUD
249270	NEEDLE BAR THREAD GUIDE
249270	NEEDLE BAR FRAME CPL. NOS. 200172, 210542 AND 224387
200125	NEEDLE BAR FRAME HINGE STUD
200175	NEEDLE BAR FRAME HINGE STUD
249270	NEEDLE BAR FRAME HINGE STUD




107 G 235 - 50 (0671)

200074-850	PRESSER FOOT SCREW
200086-833	PRESSER BAR POSITION GUIDE LEVER PINCH SCREW
200132-850	TAKE-UP LEVER OILING FELT SCREW
200260-850	PRESSER BAR LIFTING/RELEASING LEVER BRACKET
	GUIDE SCREW
200352-833	PRESSER BAR POSITION GUIDE SET SCREW
200352-833	PRESSER BAR BUSHING SET SCREW
200475-850	PRESSER BAR BUSHING (UPPER) THUMB SET SCREW
200653-850	PRESSER BAR LIFTER HINGE SCREW
201497-850	PRESSER BAR THUMB SCREW (PRESSURE REGULATING)
202401	TAKE-UP LEVER OILING FELT
202338	PRESSER BAR CPL. NOS. 200074 AND 244033
202337	PRESSER BAR POSITION GUIDE
202335	PRESSER BAR POSITION GUIDE LEVER WITH 200086
206608	PRESSER BAR LIFTING/RELEASING LEVER BRACKET
	SPRING

207072	PRESSER BAR BUSHING
210758	PRESSER BAR SPRING (LIGHT)
224478	PRESSER BAR BUSHING (UPPER)
224479	PRESSER FOOT
236106	PRESSER BAR SPRING STOP ROD
244033	PRESSER BAR (HOLLOW)
244084	PRESSER BAR BUSHING (UPPER) THUMB SET SCREW
	PACKING FIBER
508157	PRESSER BAR LIFTING/RELEASING LEVER BRACKET
508215	PRESSER BAR LIFTER
508219	PRESSER BAR WASHER

PART NO. DESCRIPTION

PART NO. DESCRIPTION




107 G 235 - 60 (0671)

50305-850	THREAD STUD SET SCREW
140321-850	THREAD CONTROLLER SPRING REGULATOR SET SCREW
200287-833	THREAD RETAINER STUD SET SCREW
200382-850	THREAD GUIDE SCREW
202410	THREAD CONTROLLER SPRING
210956	THREAD RETAINER BRACKET WITH 200397
210957	THREAD RETAINER STUD
210958	THREAD RETAINER STUD COLLAR
210992	THREAD RETAINER SPRING
210993	THREAD RETAINER SLEEVE
223438	TENSION SPRING
244048	TENSION DISC (BACK)
244049	TENSION DISC (FRONT)
263547	TENSION RELEASE WASHER

263548	TENSION RELEASING PIN
263550	TENSION STUD WASHER
263552	THREAD CONTROLLER SPRING REGULATOR WITH 50305
350613-806	TENSION STUD WITH 263550
500795	TENSION THUMB NUT
508179	TENSION CPL. NOS. 202410, 223438, 244048, 244049, 263547, 263548, 263552, 350613, 500795 AND 508180
508180	TENSION SPRING WASHER
508182	TENSION RELEASE PLUNGER
508196	THREAD RETAINER BRACKET CPL. NOS. 210957, 210958, 210992, 210993 AND 210956

NEEDLE VIBRATING MECHANISM





107 G 235 - 70 106711

200054-850	NEEDLE BAR FRAME PITMAN PINCH SCREW
200230-850	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET HINGE AND STOP SCREW (2)
200378-850	NEEDLE VIBRATING GEAR SHAFT COLLAR SET SCREW (2)
200382-850	NEEDLE VIBRATING GEAR SET SCREW (2)
200383-850	NEEDLE VIBRATING REGULATING SCREW CHECK SCREW
200383-850	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET FLANGE SCREW (2)
200429-850	NEEDLE VIBRATING REGULATING SCREW
200607-850	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET PLUNGER SPRING STOP SCREW
201525-850	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET HINGE AND STOP SCREW NUT (2)
202277	NEEDLE BAR FRAME PITMAN OIL PACKING (WICK)
202300	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET
202301	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET PLUNGER

203172	NEEDLE VIBRATING GEAR FRICTION WASHER
210550	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET CPL. NOS. 202300, 210552 AND TWO EACH 200256 AND 201525
210552	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET FLANGE WITH TWO 200383
210556	NEEDLE BAR FRAME PITMAN CPL. NOS. 200054 AND 202277
210559	NEEDLE VIBRATING GEAR SHAFT COLLAR WITH TWO 200378
210699	NEEDLE VIBRATING GEAR (SPIRAL) WITH TWO 200382
508164	NEEDLE VIBRATING GEAR SHAFT
508211	NEEDLE VIBRATING ECCENTRIC REGULATING BRACKET PLUNGER SPRING

PART NO. DESCRIPTION


PART NO. DESCRIPTION



107 G 235 - 80 (0671)


200566-850	NEEDLE VIBRATING GEAR SHAFT FLANGE SCREW (3)
500345-850	NEEDLE VIBRATING GEAR SHAFT FLANGE COVER SCREW (3)
508170	NEEDLE VIBRATING GEAR SHAFT FLANGE
508171	NEEDLE VIBRATING REGULATION ADJUSTING UNIT CPL.
	NOS. 508172 TO 508174

508172	NEEDLE VIBRATING GEAR SHAFT FLANGE COVER
508173	BIGHT AMPLITUDE ADJUSTING KNOB
508174	BIGHT AMPLITUDE ADJUSTING KNOB RETAINER



- 200054-850 PULLER FEED ROLL (UPPER) BAR POSITION GUIDE LEVER PINCH SCREW
- 200054-850 PULLER FEED ROLL (UPPER) BAR BRACKET SUPPORT PINCH SCREW
- 200256-850 PULLER FEED ROLL (UPPER) BAR BRACKET SCREW
- 200347-033 PULLER FEED ROLL (UPPER) BAR POSITION GUIDE SET SCREW
- 200352-033 PULLER FEED ROLL (UPPER) BAR BRACKET SET SCREW
- 200374-033 PULLER FEED ROLL (UPPER) BRACKET SET SCREW
- 200378-850 PULLER FEED ROLL (UPPER) HINGE STUD SET SCREW
- 200378-850 PULLER FEED ROLL (UPPER) BRACKET POSITION SCREW
- 200550-850 PULLER FEED ROLL (UPPER) BAR LIFTER HINGE SCREW
- 200550-850 PULLER FEED ROLL (UPPER) BAR LIFTING BRACKET SET SCREW
- 201458-850 PULLER FEED ROLL (UPPER) BAR THUMB SCREW
- 224403 PULLER FEED ROLL (UPPER) RUBBER FACED
- 224404 PULLER FEED ROLL (UPPER) BAR LIFTING BRACKET WITH 200352
- 236112 PULLER FEED ROLL (UPPER) BAR POSITION GUIDE
- 236113 PULLER FEED ROLL (UPPER) BAR POSITION GUIDE LEVER WITH 200054

- 237015 PULLER FEED ROLL (UPPER) BAR LIFTER STOP PIN
- 237021 PULLER FEED ROLL (UPPER) BAR
- 237023 PULLER FEED ROLL (UPPER) BAR BRACKET SUPPORT WITH 200054
- 237026 PULLER FEED ROLL (UPPER) BAR SPRING
- 237027 PULLER FEED ROLL (UPPER) BAR SPRING WASHER
- 237028 PULLER FEED ROLL (UPPER) BRACKET CPL. NOS. 200374, 200378 AND 200396
- 237029 PULLER FEED ROLL (UPPER) HINGE STUD
- 237037 PULLER FEED ROLL (UPPER) BAR LIFTER
- 508217 PULLER FEED ROLL (UPPER) BAR BRACKET CPL. 200550, 201458, 224484, 236112, 237021, 237026, 237027, 237028, 237037 AND 508218
- 508218 PULLER FEED ROLL (UPPER) BAR BRACKET CPL. NOS. 200347, 200352 AND 237015




107 G 235 - 100 (0671)

200106-850 FEED DOG SCREW (2)
 200383-850 FEED DRIVING ROCK SHAFT STOP COLLAR SET SCREW (4)
 201522-850 FEED BAR HINGE SCREW (DRIVING)
 202623-850 FEED HINGE SCREW (DRIVING) NUT
 200641-850 FEED DRIVING ROCK SHAFT

202625 FEED DRIVING ROCK SHAFT STOP COLLAR (2) WITH
 FOUR 200383
 210512 FEED BAR
 210513 FEED BAR CPL. NOS. 200641, 201522, 202623 AND 210512
 210516 FEED DOG

PART NO. DESCRIPTION


PART NO. DESCRIPTION



107 G 235 - 110 (0671)

1518-B50	PULLER FEED CLUTCH DRIVING CRANK HINGE SCREW NUT
1620-B50	PULLER FEED CLUTCH DRIVING CONNECTION HINGE SCREW NUT
200035-B50	PULLER FEED CLUTCH DRIVING CRANK PINCH SCREW
200039-B50	PULLER FEED ROLL LOWER SHAFT BRACKET SCREW (4)
200337-B50	PULLER FEED CLUTCH CAP RETAINING SCREW STUD SCREW
200374-B50	PULLER FEED ROLL LOWER SET SCREW
200396-B50	PULLER FEED ROLL LOWER SHAFT COLLAR SET SCREW (2)
201201-B50	PULLER FEED CLUTCH DRIVING CRANK HINGE SCREW
201531-B50	PULLER FEED CLUTCH CAP RETAINING SCREW STUD SCREW NUT


205797	PULLER FEED ROLL LOWER SHAFT COLLAR WITH 200386
224480	PULLER FEED CLUTCH DRIVING CONNECTION
224478	PULLER FEED ROLL LOWER SHAFT
225585	PULLER FEED CLUTCH DRIVING CRANK HINGE SCREW WASHER
237007	PULLER FEED CLUTCH DRIVING CRANK WITH 200035
237077	PULLER FEED ROLL LOWER RUBBER FACED CPL NOS. 200374 AND 200396
237019	PULLER FEED ROLL LOWER SHAFT BRACKET 2
500378-B50	PULLER FEED CLUTCH DRIVING CONNECTION HINGE SCREW



107 G 235 - 120 (0671)

1036-830 PULLER FEED CLUTCH (DRIVE) CONNECTION SET SCREW
 50375-806 PULLER FEED CLUTCH SLEEVE SET SCREW 1/2
 68152 PULLER FEED CLUTCH ROLLER PLUNGER 1/6
 131717 PULLER FEED CLUTCH ROLLER 1/6
 131725 PULLER FEED CLUTCH WASHER
 200106-833 PULLER FEED CLUTCH CAP SCREW 1/2
 200570-850 PULLER FEED COVER PLATE SCREW 1/2
 201457-850 PULLER FEED CLUTCH CAP RETAINING SCREW STUD
 224488 PULLER FEED CLUTCH (BRAKE) CPL NOS 224488 AND 263574
 224489 PULLER FEED CLUTCH (BRAKE) CPL NOS 224488 AND 263574
 224490 PULLER FEED CLUTCH (DRIVE) CPL NOS 224490 AND 263574
 224491 PULLER FEED CLUTCH (DRIVE) CPL NOS 224491 AND 263574


224492 PULLER FEED CLUTCH (DRIVE) CPL NOS 224492 AND 263574
 224493 PULLER FEED CLUTCH ROLLER SPRING 1/6
 224494 PULLER FEED CLUTCH SLEEVE WITH TWO 50375
 224495 PULLER FEED CLUTCH CPL NOS 131725, 201457, 224489,
 224490, 224492, 224493, 268442 WITH THREE 200106 AND
 SIX EACH 68152, 131717 AND 224494
 237016 PULLER FEED COVER PLATE
 263574 PULLER FEED CLUTCH ROLLER WEAR PLATE 1/6
 268442 PULLER FEED CLUTCH (DRIVE) CONNECTION CPL NOS
 1036 AND 350636
 350636-833 PULLER FEED CLUTCH (DRIVE) CONNECTION FINISH SCREW



107 G 235 - 130 (0671)

200038-850	FEED DRIVING CONNECTION CRANK PINCH SCREW
200054-850	FEED LIFTING CONNECTION CRANK PINCH SCREW
200344-850	FEED DRIVING CONNECTION PINCH SCREW
200382-850	FEED LIFTING CONNECTION PINCH SCREW
200378-850	FEED LIFTING CONNECTION CRANK SET SCREW
200367-830	FEED LIFTING CONNECTION ECCENTRIC SET SCREW
200360-830	NEEDLE VIBRATING FINION SET SCREW 2
200437-850	FEED LIFTING CONNECTION ECCENTRIC POSITION SCREW
200345-850	FEED DRIVING CONNECTION HINGE SCREW
200545-850	FEED LIFTING CONNECTION HINGE SCREW
201518-850	FEED DRIVING CONNECTION HINGE SCREW NUT
201518-850	FEED LIFTING CONNECTION HINGE SCREW NUT
201207	FEED DRIVING CONNECTION CPL. NOS. 200054 AND 203101
201306	FEED LIFTING CONNECTION CPL. NOS. 200054 AND 203101


202624	FEED DRIVING CONNECTION CRANK WITH 200038
203101	FEED LIFTING CONNECTION OIL PACKING WICK
203101	FEED DRIVING CONNECTION OIL PACKING WICK
210569	FEED LIFTING CONNECTION CRANK CPL. NOS. 200050, 200378 AND 210545
210645	FEED LIFTING CONNECTION CRANK
210700	NEEDLE VIBRATING FINION SPIRAL WITH TWO 200382
266053	FEED LIFTING CONNECTION ECCENTRIC CPL. NOS. 200382 AND 200437
396530	FEED LIFTING CONNECTION CPL. NOS. 200545, 201518, 210589 AND 210569
396533	FEED DRIVING CONNECTION CPL. NOS. 200545, 201518, 210589 AND 210569



107 G 235 - 140 (0671)

200327-833	ARM SHAFT CONNECTION BELT PULLEY SET SCREW
200383-850	FEED DRIVING ECCENTRIC REGULATING SCREW CHECK SCREW
200429-850	FEED DRIVING ECCENTRIC REGULATING SCREW
200602-850	ARM SHAFT CONNECTION BELT PULLEY POSITIONING SCREW
200607-850	FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER SPRING STOP SCREW
201014-850	FEED DRIVING ECCENTRIC REGULATING BRACKET STOP AND HINGE SCREW (2)
201525-850	FEED DRIVING ECCENTRIC REGULATING BRACKET STOP SCREW AND HINGE SCREW (2)
202253	ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)


202300	FEED DRIVING ECCENTRIC REGULATING BRACKET
202301	FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER
202635	ARM SHAFT CONNECTION BELT PULLEY CPL. NOS. 200327, 200602 AND TWO 202253
203098	FEED DRIVING ECCENTRIC REGULATING BRACKET CPL. NOS. 202300, 202635 AND TWO EACH 201014 AND 201525
224400	ARM SHAFT CONNECTION BELT REINFORCED REG. FLENE
237523	FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER SPRING
508155	FEED REGULATING SPINDLE INSERT



107 G 235 - 160 (0671)

200076-850	BOBBIN CASE STOP SCREW
210764-850	HOOK WASHER NEEDLE GUARD SCREW
200076-850	BOBBIN CASE TENSION SPRING SCREW
210846-850	HOOK GIB SCREW (3)
210735-850	BOBBIN CASE LATCH STOP SCREW
200964-850	BOBBIN CASE TENSION SPRING REGULATING SCREW
210536	HOOK GIB
210541	HOOK WASHER NEEDLE GUARD
210734	BOBBIN CASE LATCH LEVER
210735	BOBBIN CASE LATCH FULCRUM PIN
210736	BOBBIN CASE LATCH SPRING
210764	BOBBIN CASE STOP
210914	BOBBIN CASE CAP


210913	BOBBIN CASE LATCH
210914	BOBBIN CASE LATCH CPL. NOS. 210734, 210735 AND 210913
224432	HOOK (SEWING)
224433	HOOK CPL. NOS. 210536, 210541, 224432 WITH THREE 200596
224440	BOBBIN CASE CAP CPL. NOS. 200592, 201016 AND 508530
224441	BOBBIN CASE CAP CPL. NOS. 200964, 210735, 210914 AND 224440
224442	BOBBIN CASE CPL. NOS. 210846 AND 224441
224443	HOOK AND BOBBIN CASE CPL. NOS. 224433 AND 224442
233028	BOBBIN
508530	BOBBIN CASE TENSION SPRING



107 G 235 - 170 '0671)

200082	FOOT LIFTER LEVER EXTENSION SCREW 12"
200242	FOOT LIFTER LIFTING LEVER HINGE SCREW
200273	FOOT LIFTER LIFTING LEVER SPRING SCREW
224475	FOOT LIFTER LIFTING LEVER
224476	FOOT LIFTER LIFTING LEVER EXTENSION





224486	FOOT LIFTER LIFTING LEVER ROD
232131	FOOT LIFTER LIFTING LEVER WASHER
233390	FOOT LIFTER LIFTING LEVER WASHER
508195	FOOT LIFTER LIFTING LEVER SPRING







107 G 235 - 190 (0671)

001K05-ES0 ATTACHMENT SCREW
 228391 D. 1/2" x 1/4" WITH FOUR 511599
 511599-003 D. 1/4" x 1/4" WOOD SCREW (4)

512021 GROUNDING WIRE WASHER
 603271 GROUNDING WIRE




107 G 235 - 200 (0671)



107 G 235 + 210 (0671)

120440 SCREW DRIVER (LONG)
225554 WRENCH (STEEL)


228476 SCREW DRIVER (ROBBIN CASE)
239352 WRENCH (HEXAGON)



107 G 235 - 220 (0671)

200530-650 FOOT LIFTER LIFTING LEVER ROD COUPLING
SCREW
200530 FOOT LIFTER LIFTING LEVER ROD COUPLING WITH
200530

228430 FOOT LIFTER LIFTING LEVER CHAIN
228440 FOOT LIFTER LIFTING LEVER CPL. NOS. 228430 AND
TWO 511591
511591-805 FOOT LIFTER LIFTING LEVER MOUNTING WOOD SCREW (2)



107 G 235 -, 230 (0671)

500416-850 PULLEY SET SCREW
500417-819 STOP LATCH TRIP LEVER HINGE SCREW
500418-819 STOP LATCH SCREW
500419-819 FRAME CLAMP SCREW
500420-819 TENSION BRACKET SCREW
500622-819 TENSION STUD THUMB NUT
503780 UNIVERSAL BODIN WINDER FOR TV BELT DRIVES CPL.
NOS. 500417, 500418, 500419, 500903, 500904, 500906,
500907, 500908, 500909, 500910, 500911, 500912,
500913, 500914, 500915, 500916 AND 500922
BODIN WINDER AND TENSION BRACKET BASE
500903 FRAME WITH 500905
500905 FRAME GIL. CLIP (PLASTIC)
500906 FRAME HINGE PIN
500907 FRAME SPRING PLUNGER
500908 FRAME SPRING
500909 SPINDLE

503910 PULLEY WITH 500416
503911 STOP LATCH THUMB LEVER
503912 STOP LATCH TRIP LEVER
503913 STOP LATCH THUMB LEVER HINGE JOINT STUD
503914 STOP LATCH
503915 BRACKET (RUBBER)
503916 BRAKE CLAMP
503917 TENSION BRACKET WITH 503918
503918 TENSION STUD
503919 TENSION DISC
503920 TENSION SPRING
503921 TENSION BRACKET SCREW WASHER
503922 TENSION BRACKET CPL. NOS. 500420, 500502, 503917,
503920, 503921 AND TWO 503919
511604-B95 DOBBIN WINDER MOUNTING WOOD SCREW (2)